


DAIKIN

**INSTALLATION
MANUAL**

Digital I/O PCB

EKRP1HBAA




4PW54621-1 00000005


4PW54621-1

EKHBH/X


1




2




3




4




5



6




7




ALARM ON/OFF OUTPUT (YC-Y1) 1 A 230 V
UNIT ON/OFF OUTPUT (YC-Y2) 1 A 230 V
SOLAR INPUT (YC-Y3) = 230 V


E(D/B)(H/L)




1




2




3




4



5









6




7

ALARM ON/OFF OUTPUT (YC-Y1) 1 A 230 V
 UNIT ON/OFF OUTPUT (YC-Y2) 1 A 230 V
 SOLAR INPUT (YC-Y3) = 230 V


EKHBRD




NOTES



NOTES



NOTES



DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium